

Exploded View of LASH MASTER REEL

PART NO.	
101	CRANK NUT
102	CRANK ASSEMBLY
103	ADJUSTING KNOB SCREW
104	TENSION ADJUSTING KNOB
105	ADJUSTING KNOB SPRING WASHER
106	POST AND SPACER SCREW
107	UPPER COVER ASSEMBLY
108	TENSION CAM
109	PLASTIC SPACER
110	SPOOL PINION
111	SPOOL ASSEMBLY
112	LEVEL WIND SHAFT AND GEAR ASSEMBLY
113	ROLLER PINION RETAINER RING
114	ROLLER PINION
115	ROLLER RATCHET

PART NO.	
116	RATCHET SPRING
117	ROLLER ASSEMBLY
118	TENSION SPRING
119	INNER COVER ASSEMBLY
120	RIDER ASSEMBLY
121	PAWL
122	PAWL RETAINER
123	PAWL RETAINER SCREW
124	UPPER ROLLER BRACKET ASSEMBLY
125	SHAFT HOUSING
126	PILLAR POST
127	POLE MOUNT
128	SPACER
129	LEVEL WIND GUIDE
130	LOWER PLATE ASSEMBLY

The exploded view is your guide for disassembling and re-assembling of the reel.